



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS

R1



R2



DARK GREEN H330
C330

FLESH H51
C51

KHAKI GREEN C54

TAN H44
C44

SEMI GLOSS BLACK C92

01
?
02
?
03



PAINT INSTRUCTION

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
SEMI GLOSS BLACK		C92
TAN	H44	C44
FLESH	H22	C22

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H330	C330
KHAKI GREEN		C54