



USE A SAW TO REMOVE SUPPORTS  
FROM 3D PRINTED PARTS



**R1**



**R2**



**R3**



**R4**



**PAINT INSTRUCTION**

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
SEMI GLOSS BLACK		C92
DARK GRAY	H68	C32
FLESH	H51	C51

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
FIELD GREEN	H340	C340
DARK GREEN	H330	C330
KHAKI	H55	C55