



USE A SAW TO REMOVE SUPPORTS  
FROM 3D PRINTED PARTS

**DETAILS AFTER REMOVAL  
FROM SUPPORTS**



**PAINT INSTRUCTION**

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H64	C23
FIELD GRAY	H48	C52
YELLOW	H4	C4
SEMI GLOSS BLACK		C92
MEDIUM SEA GRAY		C335
FLESH	H51	C51