



USE A SAW TO REMOVE SUPPORTS  
FROM 3D PRINTED PARTS

**DETAILS AFTER REMOVAL  
FROM SUPPORTS**





PAINT INSTRUCTION

| # | COLOR            | GUNZE / AQEOUS | GUNZE / MR.COLOR |
|---|------------------|----------------|------------------|
| A | CHARACTER WHITE  | H107           | C107             |
| B | NEUTRAL GRAY     | H53            | C13              |
| C | SEMI GLOSS BLACK |                | C92              |
| D | KHAKI            | H55            | C55              |

| # | COLOR             | GUNZE / AQEOUS | GUNZE / MR.COLOR |
|---|-------------------|----------------|------------------|
| E | NAVY BLUE         | H54            | C14              |
| F | BLUE              | H5             | C5               |
| G | FLESH             | H51            | C51              |
| H | RUSSET ROST BRAUN |                | C81              |