



USE A SAW TO REMOVE SUPPORTS  
FROM 3D PRINTED PARTS

DETAIL AFTER REMOVAL  
FROM SPRUES





USE 01+02 FOR OIL BARREL  
USE 03+04 FOR TOXIC WASTE BARREL

SEMI GLOSS BLACK C92

KHAKI H81 C55

**PAINT INSTRUCTION**

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H64	C23
NEUTRAL GRAY	H53	C13
KHAKI	H81	C55

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H64	C23
NEUTRAL GRAY	H53	C13
STEEL	H18	C28