



USE R6 AND R7 ONLY WITH OPEN COCKPIT



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS



PAINT INSTRUCTION

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
FIELD GREEN	H340	C340
LIGHT GULL GRAY	H11	C11
FLESH	H22	C22

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
SEMI GLOSS BLACK		C92
DARK GREEN	H330	C330
KHAKI	H55	C55
GRAY	H308	C308