



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS





COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
SEMI GLOSS BLACK		C92
DARK GRAY	H68	C32
FLESH	H51	C51

PAINT INSTRUCTION

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H330	C330
KHAKI GREEN		C54