



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS



R1



R2



R3



R4



COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
SEMI GLOSS BLACK		C92
DARK GRAY	H68	C32
FLESH	H51	C51

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
FIELD GREEN	H340	C340
DARK GREEN	H330	C330
KHAKI	H55	C55

PAINT INSTRUCTION