



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS



COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
	H64	C23
	H52	C12
	H53	C13
	H51	C51
	H79	C39

