



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS

**DETAILS AFTER REMOVAL
FROM SUPPORTS**





PAINT INSTRUCTION

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
FLESH		C51
NEUTRAL GRAY	H53	C13
DARK SEAGRAY	H75	C25

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H303	C303
OLIVE DRAB	H304	C304
MEDIUM SEA GRAY		C335