



USE A SAW TO REMOVE SUPPORTS  
FROM 3D PRINTED PARTS

**DETAILS AFTER REMOVAL  
FROM SUPPORTS**



**R1**



**PAINT INSTRUCTION**

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
FLESH		C51
BROWN		C512
GRAY	H307	C307

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
GRAY GREEN	H56	C56
GRAY GREEN	H364	C364
BLUE GRAY	H74	C74