



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS



DARK GRAY H68
C32

KHAKI GREEN C54

01 ? 02 ? 03

SEMI GLOSS BLACK C92

FLESH H51
C51

DARK GREEN H330
C330

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
SEMI GLOSS BLACK		C92
DARK GRAY	H68	C32
FLESH	H51	C51

PAINT INSTRUCTION

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H330	C330
KHAKI GREEN		C54