



 USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS

**DETAILS AFTER REMOVAL
FROM SUPPORTS**



FLESH H51
C51

FIELD GRAY H48
C52

MEDIUM SEA GRAY C335

SEMI GLOSS BLACK C92

PAINT INSTRUCTION

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
MEDIUM SEA GRAY		C335
FLESH	H51	C51

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
SEMI GLOSS BLACK		C92
FIELD GRAY	H48	C52