



USE A SAW TO REMOVE SUPPORTS
FROM 3D PRINTED PARTS

**DETAILS AFTER REMOVAL
FROM SUPPORTS**



NEUTRAL GRAY H53
C13

FLESH H51
C51

DARK GREEN H64
C23

SANDY YELLOW H64
C23

SEMI GLOSS BLACK C92

OLIVE DRAB H52
C12

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
DARK GREEN	H64	C23
OLIVE DRAB	H52	C12
SANDY YELLOW	H79	C39

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
NEUTRAL GRAY	H53	C13
FLESH	H51	C51
SEMI GLOSS BLACK		C92