RES/KIT™

RESIN PARTS
FOR SCALE PLASTIC KITS

A-7 (E, D) "CORSAIR II"
EXHAUST NOZZLE FOR TRUMPETER KIT

INSTRUCTION RSU32-0062

CUT

USE A SAW TO REMOVE SUPPORTS FROM **3D PRINTED PARTS**

R3

R2

R4

R5

R6

R7

R1

1

R1

R2

2

R3

R4

3

STEP 2

STEP 1

RES/KIT™
RESIN PARTS
FOR SCALE PLASTIC KITS

A-7 (E, D) "CORSAIR II"
EXHAUST NOZZLE FOR TRUMPETER KIT

INSTRUCTION RSU32-0062

4

STEP 3

R5

R7

?

R6

R6 - USE WITH "E" MODIFICATION
R7 - USE WITH "D" MODIFICATION

PART FROM
THE KIT

CUT ALONG THE LINE

STEP 4