


 USE A SAW TO REMOVE SUPPORTS FROM 3D PRINTED PARTS


### DETAILS AFTER REMOVAL FROM SUPPORTS





**STEPS 1-5 SHOULD BE PERFORMED BEFORE ASSEMBLING THE MAIN MODEL BEFORE STEP 18 IN ICM KIT INSTRUCTION**


**1**




**DRILL A HOLE  
D=3 MM**

**PART E1  
FROM ICM KIT**


**2 NOSE LANDING GEAR**




3




4




5



**8 LEFT LANDING GEAR REPLACE STEPS 45, 48-50 FROM ICM KIT INSTRUCTION**




**9**





STEP 9


R1



STEP 8




LEFT VIEW




RIGHT VIEW


**11** RIGHT LANDING GEAR REPLACE STEPS 45, 54-56 FROM ICM KIT INSTRUCTION





**12**





STEP 12




R2



STEP 11




LEFT VIEW




RIGHT VIEW

**14** TO SIMULATE WIRING FOR THE BRAKE, TAKE A WIRE  $D = 0.5\text{ MM}$



**FOR STEP 57  
FROM ICM KIT**



**FOR STEP 51  
FROM ICM KIT**

